



Installation Steps

1 Place/position the mat in the right place between the round tubes/fences.
 ⚠️ Make sure the black side of the mat is at the top.

2 Centre the mat between the round tubes/fence.

3 Secure the mat to the round tubes at at least 4 connection points with rope.
 Tie the rope through the holes of the mat around the round tubes.
 ⚠️ Make sure the mat can not move.
 Cut off the excess rope.

3A **Optional:** Securing the mat at 4 fixing points with AHC anchors in concrete.
 Position the bottom plate on the ground and pre-drill the holes in concrete.
 Place the tabs of the top plate through the round holes in the mat.
 Fasten the top plate to the bottom plate with M12 bolts.
 ⚠️ Make sure the mat can not move.

4 Connect the hose using the GK coupling of the supply hose.

5 Securing the hose to the mat with at least 4 tie-wraps to prevent movement.
 ⚠️ Make sure the hose comes out of the mat in a good loop. Do not attach the hose too tight in one direction at the exit of the mat to prevent leakage.

6 ⚠️ Safely arranging excess hose out of reach from cows.
 Firmly secure the hose to the round tube with at least 2 tie-wraps to prevent movement. Make sure the hose makes a good loop.

⚠️ No kinks or sharp bends at hose.

7 ✅ **Congratulations** your MS AutoHoofClean has been successfully installed!

Contact

The Schippers Group B.V.
 Smaragdweg 60
 5527 LB Hapert
 The Netherlands

Phone: + 31 (0)497 339 787
 E-mail: klantenservice.nl@schippers.eu
 Website: www.msschippers.com

Scan QR-code for video installation instruction