

Instructions to prepare for the feed trough coating

The feed trough should be spotless, grease-free and dry when the coating is applied. For a good result, it is important to prepare well. Therefore, we recommend to follow these steps. Store the delivered products in a warm and dry place (tank room, office or hygiene lock are suitable areas).

Pre-treatment of the feed trough

- Clean the feed trough so that it looks clean at least 1 day before coating the feed trough.

Sanding to prepare for coating

- Sanding should take place when the feed trough is still damp, in order to avoid dusting.
- Sand any pebbles that stick out before coating, in order to prevent them from sticking out later as well.
- Sanding should be done with an MS diamond sanding disc. The pebbles should only be sanded lightly, so that about 1 mm is taken off. There is no need to sand them completely off.

ATTENTION!

The floor must be sanded before your consultant starts applying MSE Floorequalcoat.

Making the feed trough grease-free

- Apply MS Cementex for a grease-free surface.
- Dilute MS Cementex with water (ratio 1:10) and distribute it over a still wet/moist feed trough. 10 litres of solution are sufficient for a surface area of 10 m². If you don't have the instructions yet, you can find detailed instructions on how to use MS Cementex at www.schippers.nl.
- Brush in the divided MS Cementex with a clean broom and rinse it with plenty of water, after letting it soak for about an hour. This can be done with high or low pressure.
Attention! Rinse MS Cementex with plenty of water and do not let it dry. After this treatment, make sure that no feed or other organic dirt gets onto the feed trough.
- In the evening, dab any wet spots with a dry cloth or sponge, so that the floor has enough time to dry by the next day.

To prepare for coating

- Make sure that the feed trough has been swept clean.
- Attach the coat roller and pick roller to the bracket provided for this purpose, then fasten them to the handle with a nail or screw together with the floor squeegee.
- Make sure that the following items are ready before you start:
 - A piece of cardboard / plate to mix on
 - Extension cable to the mixing point
 - Bring the cans (or entire pallet) to the mixing point
 - A rental mixerPrepare your mixing point near the feed trough.
- By appointment, your consultant will start with the coating of the feed trough once all the preparations have been completed.
- We expect that to start and finish the work, you will need at least two people.

For any questions, please contact your consultant.