

MOUNTING INSTRUCTION




STRAW HOLDER FOR FARROWING BOX



ACO FUNKI A/S
Kirkevænget 5
DK-7400 Herning

Tel. +45 9711 9600
www.acofunki.com


DANISH DESIGN | GERMAN QUALITY | GLOBAL EXPERIENCE




2900703 HAY RACK FOR FARROWING PENS

GRILL FOR HAY RACK FARROWING PENS
HAY RACK COVER WITH HOLES


Assembly and installation on farrowing pen




The straw holder should be mounted as far forward as possible on the farrowing pen.




When mounting a straw holder on the wings of the farrowing pen, 4 U-bolts, 8 nuts, and 8 screws must be used.




Straw holder on farrowing pen




Straw holder on farrowing pen F200S.
Can be placed on either side.



Straw holder on farrowing pen XL.
Can be placed on either side.



Straw holder on Welsafe farrowing pen.
Mounted on the first and second pipes in
the partition. Can also be mounted on the
second and fourth pipes. Can be placed on
both sides.



Straw holder on Farrow Comfort. Mounted on the
first and second pipes in the partition. Can also
be mounted on the second and fourth pipes. It is
installed on a solid partition that does not have an
opening function

